



- CZ_t = clear-zone width on tangent section
- CZ_c = clear-zone width on horizontal curve
- L = transition length (ft) = $3.1V$
- V = design speed (mph)

**CLEAR-ZONE TRANSITION FOR CURVE ADJUSTMENT,
RADIUS ≤ 3000 ft**

Figure 49-2C