

---

### PRESTRESSED BEAM DESIGN TIPS AND BEST PRACTICES

#### Hold-Down Points

While not recommended as standard practice, but when needed, hold-down points may be staggered from 15" to 18" in order to facilitate the use of more draped strands and to minimize the hold-down force at an individual location.