



**GENERAL NOTES**

1. See Standard Drawing E 802-SNGP-01 through 10 for breakaway details and dimensions. Use post size W 6 x 9.
- ② The fuse plate shall be 6 in. below the lowest fastener of the sign.
3. See Standard Drawing E 805-SGFB-01A for conduit and detector housing details.

**FLASHING BEACON WITH WARNING SIGN  
ON 150 DEPTH I BEAM**

INDIANA DEPARTMENT OF TRANSPORTATION	
<b>FLASHING BEACON WITH WARNING SIGN</b>	
SEPTEMBER 2000	
STANDARD DRAWING NO. <b>E 805-SGFB-01</b>	
	<i>/s/ Anthony L. Uremovich</i> 9-01-00 <small>DESIGN STANDARDS ENGINEER      DATE</small>
<i>/s/ Firooz Zandi</i> 9-01-00 <small>CHIEF HIGHWAY ENGINEER      DATE</small>	
DESIGN STANDARDS ENGINEER	