



GENERAL NOTES

1. See Standard Drawing 802-SNGP-01 through 10 for breakaway details and dimensions. Use post size W 150 x 13.
- ② The fuse plate shall be 150 below the lowest fastener of the sign.
3. See Standard Drawing 805-SGFB-01A for conduit and detector housing details.

**FLASHING BEACON WITH WARNING SIGN
ON 150 DEPTH I BEAM**

All dimensions are in mm unless otherwise specified.

INDIANA DEPARTMENT OF TRANSPORTATION

**FLASHING BEACON
WITH WARNING SIGN**

SEPTEMBER 2000

STANDARD DRAWING NO. **805-SGFB-01**

	/s/ Anthony L. Uremovich 9-01-00 DESIGN STANDARDS ENGINEER DATE
	/s/ Firooz Zandi 9-01-00 CHIEF HIGHWAY ENGINEER DATE