Damage To State Property Assessments



What is DSP?

- Damage to State Property is a program developed to improve the states ability to collect money from insurance companies after an accident.
- The program uses cost estimates for the most commonly hit items
- This presentation will describe how to properly use those estimates when assessing damage after an accident.



How To Assess

Electronic or paper versions of the estimate form can be used to assess the damage.

Recommend using electronic version when possible

Route:	
arest Intersecting Road / Mile Marker / Interchan Crash Tag Located (Y/N): Crash Tag Located (Y/	
Crash Tag Located (Y/N): II.A.R.E. Bolir Dote: Bam Country	
ILABLE & Order #: pair Date: Been Quantity	
ILABLE & Order #: pair Date: Been Quantity	
k Order #: seir Date: Rem Quantity	
Been Quantity	
Attenuators	U
Barrels	
Cartridge	- 7
	- 1
Cartridge Unit Fender Panel	- 1
Cartridge Unit Diaphram	-
Rip Plate	
Rip Plate Unit Nose	
Rip Plate Unit Fender Panel	
Rip Plate Unit Diaphram	
REACT - Reset	
REACT - Parts Damaged	
SCI - Reset	
SCI - Parts Damaged	
	_ S
	- 1
	- 2
	- 1
	- ;
	- 1
	- 2
	- 1
	- 1
	Carningia Unit Nose Carningia Unit Nose Carningia Unit Pender Panel Rap Plana Rap Plana Rap Plana Unit Nose Rap Plana Unit Render Panel Rap Plana Unit Render Panel RAAT- Panat Damaged



http://www.digitaltrends.com



http://www.trimble.com/junost.shtml



Categories of Damage

- Guardrail / End Treatments
- Attenuators
- Signs (Sheet Sign and Panel Signs)
- Miscellaneous
- Additional Damages



Categories of Damage

- If you are ever unsure about what is damaged or damage does not correctly fit any items, select "Additional Damages" and write what is damaged.
 - Ex: Signal Cabinet, Bridge, Pavement Damage, Unique Attenuators, Cable Barrier Cut, etc.
- If no repairs will ever be performed, select "No Repairs Needed"
 - Ex: Guardrail has a small ding, but is still functional



- Guardrail will now consist of more components
 - W Beam, Thrie Beam, Curved Beam, Post Replace, Block, Post Plumb, and Transition



- W Beam Most typical guardrail beam.
- Thrie Beam Larger size of guardrail beam.
- Curved Beam Any beam that has curve in it.
 - Record entire length of piece that will need to be replaced. Usually 25' or 12.5' sections.



- Transition This includes W-beam to Thrie Beam, or connecting beam to barrier wall
- Post Replace Post cannot be reused.
 Can be wood or metal.
- Post Plumb Post can be reused, and just needs to be reset
- Block Wood block or metal bracket that holds the beam to the post.



Blocks – these are wooden, but can be metal. None are damaged here.




Post Pumb – Post is at an angle, but is not damaged.

W Beam – Report entire length if it will be replaced. If unsure about replacement, leave W-Beam blank and select "Additional Damages". Then explain the condition of the beam.



Transitions – Beam to Wall on left and W beam to Thrie beam on right. If both were damaged, mark 2 transitions.



W Beam

Thrie Beam -

Can also be found on regular runs of guardrail. Report entire length that will need replaced.



Guardrail End Treatments (GRET)

- Used to protect traffic at the beginning of guardrail runs.
- There are two types of GRET's
 - ET or SKT
 - CAT
- A sheet sign may be used to inform motorists of the hazard. If the sign is damaged, both the sign and GRET should be assessed.



ET or SKT End Treatments

The ET or SKT have an extruder head that curls the guardrail as it is pushed through.

ET PLUS

http://www.highwayguardrail.com/products/etplus.html

SKT



http://www.roadsystems.com/skt.html



ET or SKT End Treatments

Rail:

The rail is recorded as one 25' piece. After that piece, mark damage as guardrail.



Extruder Head: Can often be reused.


Posts: can be wood or metal. Hinged posts can be knocked over without being damaged.

Anchorage System:

Can be reused if parts are located and appear in good shape.



CAT End Treatments



Attenuators

- Protect traffic from solid objects, typically in medians, but not always.
- The following will discuss the different types of attenuators, how to recognize them, and how to determine the damage
- There will be different damages for each attenuator. Select all that apply.



Barrels

- Location: Typically interstate overpasses
- Each barrel damaged is to be marked as 1 regardless of size or severity of damage



http://mainstreetmaterials.com/products/safety-equipment/crash-barrels/



Cartridge Attenuators

- Common types include QuadGuard, Tau, Hex-Foam, GREAT.
- Cartridges in the attenuator designed to be crushed during an accident
- Damage Categories include cartridge, nose, fender panel, and diaphragm





Cartridge Attenuators



Mark if any damage

http://www.enterpriseflasher.com/assets/images/photo-quadguard-sys1.jpg

properly telescope.



Rip Plate Attenuators

- Common types include the TRACC
- Uses perforated metal plate in bottom instead of cartridges
- Damage categories include rip plate, nose, fender panel, and diaphragm



TRACC™ FAMILY

http://www.highwayguardrail.com/products/images/butCrashTracc.jpg



RIP Plate Attenuator

Fender Panel: Mark each panel bent enough that system would not be able to pull back. Diaphragm: **Rip Plate:** Mark if broken or Mark all with any damage twisted. Not very to them. common. Nose: Mark if damaged TRACC[™] FAMILY

http://www.highwayguardrail.com/products/images/butCrashTracc.jpg



Attenuator Damages Recap

- <u>Cartridge Damage</u>: Number of cartridges with any damage on them.
- <u>Rip Plate</u>: Metal plate in bottom of some attenuators. Used instead of cartridges. Count number of plates with any damage.
- <u>Nose</u>: the front piece of attenuator. Will likely be damaged on any front hit.
- <u>Fender Panel</u>: Meant to telescope in. Damaged if bent or unable to pull back out.
- <u>Diaphragm</u>: Metal frame on inside of units.
 Damaged if broken or twisted.



Recoverable Attenuators

- REACT's and SCI's are meant to be hit with little maintenance costs.
- They typically are pulled out and reset
- Large hits may cause damage



REACT Attenuator

- Will partially rebound on its own
- If a REACT is hit without noticeable damage to the system mark it as a reset



http://ibtta.multiview.com/userlogo/ibtta/ps/3888v4v1.jpg



REACT Attenuator

 System is damaged if any barrels are cracked or cable assemblies broken

It is okay if the barrels do not return to being perfectly round




SCI Attenuator

- Uses a hydraulic cylinder to absorb energy. Will not rebound after a hit
- If no parts appear broken, mark it as a reset
- If there appears to be any non typical damage from a large hit mark it as damaged



http://www.stinson.ca/product_details.php?c ategory_id=147&item_id=571&tab=images







- There are 4 possible choices for sheet signs
 - Sheet Sign Hit
 - Post Damage
 - Sign Damage
 - Rapid Response Stop/Yield Sign



Select all items applicable to the damaged sign

- Sheet Sign Hit
 - Mark this for every sheet sign structure involved in an accident
 - Covers cost of equipment and man hours for traveling out to the sign
- Post Damaged
 - Mark how many posts are damaged and will need to be replaced



- Sign Damaged
 - Record the square footage of the sign if it is damaged
- Rapid Response Stop/Yield Sign
 - Covers additional cost of signs that require immediate replacement or a temporary sign (Stop Signs)







Sign Hit: Sheet sign involved in accident, so mark this.

Post:

Damaged, so

length of the

post in feet.

record the

Sign: Not damaged here. If it was, measure area in square feet and record.



http://www.annarbor.com/news/dexter/more-annarborcom-photos-from-the-tornado-aftermath-in-dexter/

Urgent Response: Stop sign requires immediate replacement or a temporary sign, so mark this



There are 4 possible choices for panel signs

- Panel Sign Hit
- Aluminum Panel
- Overlay Sheeting
- I-Beams: four choices depending on sign size



As with Sheet Signs, select all items that apply to the sign

- Panel Sign Hit: Covers the cost of visiting the sign and installing/resetting sign.
- Aluminum Panel: Count the number of aluminum panels on the sign damaged.



- Overlay Sheeting: Sheet sign material that is bolted onto the panel sign. Not all signs will have this. Report square feet of damaged section
- <u>I-Beams</u>: Damaged if it is bent, twisted or cracked. There are four I-Beam choices based on sign area. Measure approximate area of the sign and mark the beam that relates to that area.



Panel Sign Hit: Mark one because a sign was in accident



Aluminum Panels:

Main structure of sign underneath sheeting. Report the number of panels that are damaged.

Overlay Sheeting:

Not on all signs. Also look at Exit Numbers at top of signs. Measure SFT of overlay sheet if damaged.

I-Beam: Count each damaged

beam. Measure sign and report under correct size.





Miscellaneous

- Cable Barriers
- Traffic Control
- Seeding
- Repair Grade
- Delineators
- Fence
- No Repairs Needed



Cable Barriers

Found in grass medians typically along interstates





Cable Barriers

- Post Damaged Any standard post that is bent or broken
- Retention Any barrier run that is not taught.
- Anchor Post Damaged Any anchor post that has been hit. Anchor posts are any post near the beginning/end of a run that appear different than the typical posts in any way.



Cable Barriers

Retention System

Cables have slack in them and will need to be retentioned. Record the number of cables with slack. (Up to 4 per system)



Anchor Hit

The first few posts of the system can be part of the anchor. These posts are much more expensive than the regular posts.



Sometimes anchor is intentionally pushed over to detention the system. If this happens, the anchor does not need to be marked as damaged.



Traffic Control

- Use when accident causes road to be closed down. NOT when repairs require road to be closed.
- Costs will be based off of actuals.
- If known exactly what was used, comment it in the notes.





Seeding and Repair Grade

- Repair grade if there are deep ruts
- Seeding if grass if area is missing
- Both are measured in square feet
- Will likely only happen when ground is wet
- Can be required due to spill or fire





nascarinformeronline.com



Seeding and Repair Grade

Calculating area of seeding and repairing grade



Total Area = Length x Width = $40' \times 10' = 400$ SFT



Delineators

- Reflective posts to help keep cars on the road.
- Typically plastic, but can be metal with a reflector button.







Fence

- Farm fence or chain link metal fence
- Recorded the number of feet damaged
- No separate items for posts, fence, etc





Additional Damages

- Can be anything that does not fit one of the items
 - Ex: Bridge, lighting, ITS Equipment, etc.
- Can be used if you are unsure about what to select
 - Ex: Will guardrail beam be replaced? What parts of attenuator need repaired?
 - It is preferred to select "Additional Damages" than selecting something incorrectly



Additional Damages

- Explain why Additional Damages has been selected.
- Good pictures may allow someone with more expertise to determine damage without visiting the site.



Questions



