

<b>Title</b>	<b>Formaldehyde in Indoor Air</b>
<b>Specimen Requirements</b>	Samples for Formaldehyde analysis will only be accepted from the Indiana State Department of Health Indoor and Radiologic Health Division or from a County Health Department.
<b>Sampling Materials</b>	Miniature impinger with 15 ml of 1% sodium bisulfite solution (prepared by ISDH Labs)  Personal sampling pump, MSA Model G or equivalent, calibrated at 1-2 liters per minute.
<b>Procedural Notes</b>	Record total sampling volume or sampling time and pump rate for total volume to be calculated. A minimum air volume of 30 liters is required (100 liters is recommended). A blank sample should be submitted with every set of samples. Mark each impinger and parafilm the impinger nipples. Make sure to note the total air volume sampled.
<b>Shipping Instructions</b>	Place impingers in “birdhouse” provided and use foam padding to prevent damage. Hand deliver to ISDH Labs  ISDH LaboratoriesIndoor Air Laboratory550 W. 16th Street, Suite BIndianapolis, IN 46202
<b>Reporting and TAT</b>	